

Lube Oil Analysis Management System

Quick Start Guide: Labels (P-Labels)




Move Forward with Confidence






- P-labels are pre-printed bar code labels used for submitting samples
- P-labels are used with a scanner when completing the label process
- The P-label must be filled out by hand and registered online to complete the process
- If you are interested in starting the P-label program please contact your system administrator

Labels: Explore Tab or Find Tab



There are two ways to find equipment to register your labels. The first is through the **Browse Tree** and the second is through the **Find Units** tab. To begin, click on the **Equipment** tab.

Equipment Hierarchy



on the *Print Labels* button.

Find Units





To select your equipment through the *Find Units* tab, search for the unit and components you want to register labels for. Next select the checkbox next to them and click on the *Print Labels* button.

Filling Out the Label



	LOS MS Lube Oil Analysis Management System							Loams /	Sele <mark>c</mark> t Admin +		English-
HOME	SAMPLES EQUIPMENT LABELS	REPORTS PREFERENCES	5					Quick S	iearch		Need Help ?
New Sam	ples History/Status										
			Filters								
R R	emove All		Select Filter		•	Ø				required fie	lds
+ Fast	Fill										
	Unit ID/Component	Sampled Date	Unit Age	Lube Age	Age Units	5		Lube		Lube	Added
â	82210 ENGINE	Jan 05, 2018	16000	851	Hr	•	SHELL "ROTELLA T3" 1	5W40	٩		
	Last Sample:04/21/2016 Unit Age:15149	Tracking Number:	P201303010001	Filter Changed:	Yes	•	Comment:	Demo Comment			
	Lube Age:213			Lube Service:	Changed	•					11

Fill out the required fields highlighted in yellow. You can also add additional comments you'd like the lab to know in the *Comment* field. <u>Please scan or</u> <u>type in the P-tracking number exactly as it is listed on your label.</u> Once all fields are filled out click the *Submit Samples* button.


Filling Out the Label



	be Oil Analysis Management Sy	S [™] stem										Select Language iin 👻 Last logir	n on 01/03/201
HOME S	AMPLES EQUIPMENT	LABELS	REPORTS	PREFERENCES							Quick Sear	ch	Need Help ?
New Sampl	History/Status												
-					Filters								
🔟 Re	move All Submit S	amples			Select Filter				• + Ø			required fie	lds
+ Fast F	ill 🧹												
				Sample	ed Date		Unit Age		Age Units		Lube		
				MMM dd, yyyy		0				T			٩
	Copy to All Sar	nples		Filter Changed:		· · · · · · · · · · · · · · · · · · ·		Comment:					
	Λ			Lube S	Lube Service:								10
	Unit ID/Componer	nt	Samp	led Date	Unit A	lge	Lube Age		Age Units		Lube	Lube	Added
â	82210 ENGINE		Jan 05, 2018		16000	851			Hr	SHELL "ROTELLA T3" 15	۹ 🗌		
	Last Sample:04/21/2016 Unit Age:15149	5	Trackin	g Number:	P20130301000)1	Filter Change	ed:	Yes 🔻	Comment:	Demo Comment		
	Lube Age:213						Lube Service	2:	Changed •				

Clicking on the **+** *Fast Fill* link allows you to save time when registering several samples at the same time. Fill out the fields that will be the same and click *Copy to All Samples.* Please be sure to enter in each separate P-label tracking number for each sample.


History/Status



This will bring you to the **History/Status** tab where you will see your registered sample label. You can now affix the label to the bottle and ship to the lab for processing.

Affix Label to Sample





Label Do's and Don't's








Label Do's

- Register your labels online before sending them to the Laboratory
- Fill out labels completely and correctly.
 - Missing information reduces the accuracy of used oil analysis reporting
- Affix label to the bottle correctly.
 - The barcode should be vertical
- Make sure the lid is on securely.
- Confirm the sample matches what was registered online

Label Don't's

- Do not send P-label samples that have NOT been registered online.
- Do not use a label for more than one sample.

History/Status



Modify Delete Submitted Date:01/05/2018 Submitted By:mmcbayne Status: Not Received Worksite:Richland County Recycling

The *History/Status* tab is where you can see all the information that was filled out on the label: the submitted date, which user submitted the sample, the status, and the worksite.

Filter History



UREAU ERITAS	Select Language 🛛 🗮 Eng Loams Admin 👻 Last login on 01/03									
HOME	SAMPLES EQUIPMENT LAB	ELS REPORTS	PREFERENCES					Quick Search	Need Help 🥐	
New Sam	ples History/Status Status Report 📄 Print Labe		Label Sheet				Filters			
			Start Position				Select Filter	T	+ 0	
 Filter History Select Date Range Today Last 30 Days Last 30 Days Only Samples in Date Range Earliest: MMM dd, yyyy Latest: MMM dd, yyyy 										
		Component	Unit	nit ID Worksite			Tracking Number	Status	Status	
			8221		Submit Search C	riteria Reset f	Form		T	
	Unit ID/Component	Sa	mpled Date	Unit Age	Lube Age	Age Units	Lube	Lub	e Added	
	82210 ENGINE	82210 ENGINE 01/05/2018		16000	851	Hours	SHELL "ROTELLA T3" 15W4	40		
	Last Sample:04/21/2016 Tra Unit Age:15149 Lube Age:0		king Number:	P201303010002	Filter Changed: Lube Service:	Yes Changed	Comment:	Demo Comment		

The *Filter History* link lets you search for previously submitted samples. Expand the box and fill out your search parameters. Once complete, click the *Submit Search Criteria* button.

Tracking a Sample




	LOSAMS [*] ube Oil Analysis Management System							Language English ▼ Last login on 01/03/2018	
		REPORTS PREFERENCES					Quick Search	Need Help ?	
New Sampl	ples History/Status								
Status Report I I I Start Position Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filters Filt									
• Filter	History								
	Unit ID/Component	Sampled Date	Unit Age	Lube Age	Age Units	Lube		Lube Added	
	82210 ENGINE	01/05/2018	16000	851	Hours	SHELL "ROTELLA T	T3" 15W40		
	Last Sample:04/21/2016 Unit Age:15149 Lube Age:0	Tracking Number:	P201303010002	Filter Changed: Lube Service:	Yes Changed	Comment:	Demo Commen	nt	
	Modify Delete Submitted Date:01/05	05/2018 Submitted By:mmcbayne	ne Status: Not Received We	orksite:Richland County Re	cycling				

You can track a sample by viewing the *Status*.

There are three different Status options that will display:

- Not Received This sample has not been received by the lab.
- **Received** This sample has been received by the lab and is in processing.
- **Completed** The sample is complete click the link to view the report.

Modify or Delete a Label




You can delete or modify information on a label as long as the sample status says *Not Received*. To do so, click the **Modify** or **Delete** links.



Status Report





The *Status Report* button lets you generate a printable PDF report of recent samples that were submitted. To print a report select the checkboxes next to the labels you'd like to print and click **Status Report**. A new window will open up with your report.





1/1



Sample Submitted History

	t Date: Jan 5, 2 t User: mmcbay		Start Date: 01/05/18 End Date: 01/05/18								
Sample Date	Statue	User Submitted	Tracking Number	Unit ID/Component	Unit Age	Lube Age	Lube	Lube Added	Fliter Change	Lube Service	Comments
01/05/18	Not Received	mmcbayne	P201303010002	82210 ENGINE	16000 Hours	851	SHELL ROTELLA T3 15W40		Yes	С	Demo Comment

To print, select *Print* from your PDF window. You can also print by using your keyboard (Hold down '**CTRL**' and the letter '**P**' at the same time).





LOAMS[®] SUPPORT DESK:

Phone: **1-800-655-4473** Email: **LOAMS@us.bureauveritas.com**

www.AnalystsIncOnline.com

www.AnalystsInc.com/LOAMS-Resource-Center