





# **Quick Start Guide**

Labels (S Labels)

## **S-Labels**





Top of Bottle 31897 Peterbilt 348 Component Lab Unit No S202424786934

- S-labels are pre-printed forms with QR codes generated from our LIMS system
- S-labels are used with a scanner when completing • the label process
- The S-label form must be filled out by hand and can • be registered online to complete the process
- If you are interested in starting the S-label • program please contact your system administrator

	Equipment & Sample Sample Registration	Page 1 of 1
BUREAU VERITAS	TSTIB S20250213061352 ORDER#: OR001023	} 376
Complete this form <u>o</u> 1. You cannot registe 2. This is the first tim	<u>onty</u> if: er samples in LOAMS e you are submitting samples for this equipment	
UNIT ID		
COMPONENT SAI	MPLED:	
Engine	(fuel type)	
Turbine	⊐Gas ⊐Steam	
Hydraulic	Gearbox (Type)	
П Pump	D Compressor (Type)	
□ New Oil	Motor (Type)	
Other (describe)		
Fuel consumed s	ince last sample	
Miles / hours sinc	e new / o'haul	
Miles / hours sinc	e oil change	
Makeup oil addeo	d Gal/Q15/L Filter changed? Y N	
Sample date	Oil changed? Y N	
UNIT/COMPONENT	INFORMATION (Complete on first sample or as needed)	
Unit Mfg / Model		
Component Mfg /	Model	
Oil Mfg / Brand or	type / Grade	
Sump capacity	Gal / Qts / L Oil additives	
Coolant type, add	itives	
Filter type, rating	No. Filters	
Sample submitte	d by:	
Company		
Attn:	li l	
Address		
City	State Zip	
Phone(	Email	
Unit / Component	Work Site	
Comments: (Recei	nt Maintenance, abnormal conditons, etc.) * 교	



### Step One: Select Component(s)

You get directed to the labels wizard

when you click the labels tab. There are two steps to create a label: Select Component(s) and Label(s) Details. In step one, you can add components by selecting the magnifying box.

Wizard	History			
1 Se	lect Component(s)	2 Label(s) Details		
		Add Com	ponent(s)	
				٩

Wizard History						
Select Component(s)	2 Label(s) Details					NEXT 🗲
	Add Component(s)			Saved Component List		
		٩		- Select -	- SAVE Clear All	
	COMPONENT	COMPONENT MAKE	COMPONENT MODEL	COMPONENT SERIAL	UNIT ID	
						NEXT 🔸

**Labels Wizard** 



#### Step One: Select Component(s)

Once you select the magnifying

box to add component(s), you can search by customer name, worksite, unit ID, unit serial number, component type, component serial number, and component make/model. Once you find the correct component, select the check box and press OK. After that, press next to move to the second step in the label process.

Wizard	History	
1 Sel	ect Component(s) (2) Label(s) Details	
	Add Component(s)	
		٩

#### SELECT ONE OR MORE COMPONENTS

	CUSTOMER abc company	WORKSITE \$	UNIT ID 💠	UNIT SERIAL \$	COMPONENT \$	COMPONENT SERIAL	ţ.
	ABC Company	Worksite 1	647836	12345	TRANSMISSION - MA	12345	-
	ABC Company	Worksite 1	647836	12345	FRONT DIFFERENTIAL	12345	
	ABC Company	Worksite 1	647836	12345	STEERING	12345	
	ABC Company	Worksite 1	647836	12345	COOLING SYSTEM	12345	
	ABC Company	Worksite 1	647836	12345	ENGINE	12345	
	ABC Company	Worksite 1	647836	12345	REAR DIFFERENTIAL	12345	
	ABC Company	Worksite 1	647836	12345	HYDRAULIC	12345	
	ABC Company	Worksite 1	647836	12345	TRANS-AUTO	12345	
	ABC Company	Worksite 1	834713		DIFFERENTIAL	D	
•	ABC Company	Worksite 1	834713		FNGINF	F	+
howing	10 rows				10	of 6 < < 🚥 >	»

CANCEL OK



#### Step Two: Label(s) Details

Here you can add the sampled date, unit age information and lube information.

Anything that is highlighted in blue is required to submit a label. **Make sure to scan or type in the S-tracking number exactly as it is listed on your label**. As a note, you can leave the tracking number field blank as a tracking number will get assigned once you submit the sample information.

Wizar	d History											
$\odot$	Select Component(s) (2) Label(s	(s) Details									← ВАСК	FINISH 🗲
FA	AST FILL-IN 🗸											
3	1897 / ENGINE	4	Unit Age:				Lube Age:			Last Sample: 02/13/2025		
s	ampled Date*	Tracking Number	Unit Age*	Age	e Units*		Lube Age*	Lube Service*		Lube*		
	02/13/2025	S2024127578637	1950	H	ir	•	1950	Sampled	•	CASTROL VECTON LONG DRN CK-4 10W30	٩	
c	omment						Lube Added	Filter Changed*		Request Oil Type		
								Yes	•			
			h									
C	ANCEL										← ВАСК	FINISH 🗲



#### Step Two: Label(s) Details

You can also use the fast fill-in to save time when submitting multiple samples. Click on the fast fill-in icon. You can enter data for as many fields as you want. Once you are done, press apply and notice the data appears for the samples below.

Wizard History		
Select Component(s)	2 Label(s) Details	
FAST FILL-IN 🗸		

History			
Select Component(s) (2 Label(s) Details			← BACK SUBMIT →
FAST FILL-IN V			
Sampled Date	Unit Age	Age Units	Lube
05/24/2023	10000	Hr •	MOBIL SHC ISO 320
Lube Age	Lube Service	Lube Added	Filter Changed
	Sampled -		No
Comment			
1			
	A	.PPLY	

### Step Two: Label(s) Details

After the required data is entered, press submit.

A pop-up screen will appear letting you know that the tracking numbers are automatically generated. Once you press "OK" you will be taken to the history tab. The samples that were submitted will be automatically checked off to make printing labels easier.



DELETE

S2024127578637

Showing 25 rows



### **Printing Labels**

Click the print labels icon to generate the labels. A new tab will pop up with the labels.



wizar	a 📕	History															
SL	bmitted	Tracking Number in S202412	27578637 × + Ad	dd Filter													:
E	DIT	DELETE										l	STATUS REPOR	RT 📙 PRINT L	ABELS 1	Label Sheet Start Posit	ion 🗘
		RACKING NUMBER \$	SAMPLED DATE 🖨	COMPANY NAME	WORKSITE \$	SUBMITTED BY \$	STATUS - Select - •	CREATED ON \$ - Select - ▼	UNIT ID \$	COMPONENT \$	LUBE \$	UNIT AGE \$	AGE UNIT \$	LUBE AGE \$	LUBE ADDED \$	LUBE SERVICE \$	FILTER CF
	S	2024127578637	02/13/2025	Rudnickis Excavating	Site1	BV Super User	In Transit	02/13/2025	31897	ENGINE	CASTROL, VECTON LONG DRN CK-4, 10W30	1950	HR	1950		Sampled	yes
Sho	wing 2	5 rows														1	×



### **Printing Labels**

You can print the labels and stick them onto you sample to send to the lab.





# Label Do's

- Register your labels online before sending them to the lab
- Fill out labels completely and correctly Missing information reduces the accuracy of used oil analysis reporting
- Affix label to the bottle correctly
- The barcode should be vertical
- Make sure the lid is on securely
- Confirm the sample matches what was registered online

# Label Don'ts

- Do not use a label for more than one sample
- Do not write on labels If you need to make changes you can do so as long as it has not been received by the lab

# **Filter History**



0	Lube Cil Analysis Nanagement System											Need Help	Search	(a) John Doe
VERITAS	HOME ACTIONS S	AMPLES LABELS EQ	UIPMENT ANALYTICS	REPORTS DISTRIBUT	ON ADMIN PREF	ERENCES								
Wizard	History													
+4	dd Filter													:
EDI	T DELETE		V								STATUS REPORT	PRINT LABELS	1 • C Label Sheet Start F	Position 💠
	TRACKING NUMBER \$	SAMPLED DATE - Select - *	COMPANY NAME ABC Worksite	SUBMITTED BY 🖨	STATUS \$		COMPONENT	¢	UNIT AGE \$	AGE UNIT 🗘	LUBE AGE	LUBE SERVICE - Select - *	FILTER CHANGED  CO	OMMENT 🗘
0	E202305314969	05/26/2023	ABC Worksite	John Doe	In Transit	234562	HYDRAULIC	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	
	E202305319214	05/26/2023	ABC Worksite	John Doe	In Transit	234562	ENGINE	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	
	E202305319426	05/26/2023	ABC Worksite	John Doe	In Transit	234562	DIFFERENTIAL	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	
	E202305317429	05/26/2023	ABC Worksite	John Doe	In Transit	234562	REAR DIFFERENTIAL	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	
	E202305317058	05/26/2023	ABC Worksite	John Doe	In Transit	234562	FRONT DIFFERENTIAL	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	
	E202305312910	05/26/2023	ABC Worksite	John Doe	In Transit	234562	TRANS-AUTO	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	
	E202305318308	05/26/2023	ABC Worksite	John Doe	In Transit	234562	STEERING	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	
	E202305312099	05/26/2023	ABC Worksite	John Doe	In Transit	234562	COOLING SYSTEM	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	
	E202305317722	05/26/2023	ABC Worksite	John Doe	In Transit	234562	TRANSMISSION - MANUAL	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	
	E202305314474	05/26/2023	ABC Worksite	John Doe	In Transit	234562	HYBRID HYDRAULIC DRIVE SYSTEM	CONOCO, HYDROCLEAR EP GO 220, ISO 220	6700	HR	6700	Sampled	yes	

The *Filter History* link lets you search for previously submitted samples. You can filter by tracking number, company name, submitted by, unit ID, status and more.





You can track a sample by viewing the **Status**. There are five different status options that will display:

In Transit – This sample has not been received by the lab

In Progress - This sample has been received by the lab and is processing

**<u>Complete</u>** – The sample is complete – click the link to view the report

**Cancelled** - This sample has been cancelled after getting registered

<u>Unknown</u> – Unknown status

## **Modify/Delete a Label**



Wizard	History					
+ Add	l Filter					
EDIT	DELETE					
		SAMPLED DATE 🗢	COMPANY NAME ABC Worksite	SUBMITTED BY 🜩	STATUS - Select - *	UNIT ID \$
	E202305314969	05/26/2023	ABC Worksite	John Doe	In Transit	234562
	E202305319214	05/26/2023	ABC Worksite	John Doe	In Transit	234562
	E202305319426	05/26/2023	ABC Worksite	John Doe	In Transit	234562

REMOVE SAMPLE	×
Do you want to delete this sample?	
	CANCEL OK

You can modify or delete information on a label as long as the sample status says "*In Transit*". To do so, find the label and click the check box on the right. Once the label has been selected, then click "Delete". Another window will pop up and select "OK".

### **Status Report**

R



ō



		1 /	1   — 1009	% +   L	)						
O Analysis Management System Sample Submitte									tted I	History	
port Date : 05/3 port User : Johr	1/2023 n Doe									Start D End D	Date : 05/26/2023 Date : 05/26/2023
Sample Date	Status	User Submitted	Tracking Number	Unit ID Comp	Unit Age	Lube Age	Lube	Lube Added	Filter Change	Lube Service	Comments
05/26/2023	In Transit	John Doe	E202305314969	234562 HYDRAULIC	6700 HR	6700	CONOCO, HYDROCLEAR EP		Yes	Sampled	

The *Status Report* button lets you generate a printable PDF report of recent samples that were submitted. To print a report, select the checkboxes next to the label(s) you would like to print and click *Status Report*. A new window will open up with your report.

GO 220, ISO 220

# LOAMS - The Lube Oil Analysis Management System





LOAMS — The Lube Oil Analysis Management System — by Bureau Veritas gives you access to real-time oil analysis data from your computer, tablet or mobile device. LOAMS is:







#### LOAMS SUPPORT DESK

Phone: 1.800.655.4473 Email: LOAMS@us.bureauveritas.com

LOAMS Platform | LOAMS Resource Center

Download the LOAMS Mobile App today: