

Quick Start Guide

Modifying Mobile Equipment Units


○ Objectives:

- 1** Access the browse tree in the equipment tab
- 2** Learn how to modify mobile equipment units in 5 easy steps
- 3** Learn how to modify components and save modifications



Modifying Mobile Equipment

- The equipment tab allows you to quickly access and manage your equipment. In this quick start guide, you'll learn how to easily:
- ✓ Modify mobile equipment units




The screenshot displays the LOAMS web application interface. At the top, the LOAMS logo and the text "Lube Oil Analysis Management System" are visible. Below the logo is a navigation menu with tabs: HOME, ACTIONS, SAMPLES, LABELS, EQUIPMENT (highlighted in red), ANALYTICS, REPORTS, DISTRIBUTION, ADMIN, CONFIG, and PREFERENCES. The main content area is titled "Equipment" and shows a breadcrumb "Equipment / Browse Equipment". A tree view structure is displayed, starting with "BUREAU VERITAS" (expanded), followed by "AGCO" (expanded), and then "BUREAU VERITAS" (expanded). Underneath, there are two work sites: "ABC Company Worksite 1" and "ABC Company Worksite 2". Each work site contains a list of equipment units, each with a checkbox and a gear icon for modification. The units listed are: 834713 International 3800, 855326 International TRUCK, 864686 International DT466E, 906754 International 7000 SERIES, and 8654323 International 1400 SERIES.

Modifying Mobile Equipment

1 The first step begins clicking the equipment tab and selecting the browse equipment page. From here, find the correct worksite and see their list of equipment.

2 After clicking the worksites folder, you'll see their list of units on the right side. From here, find the unit you plan to modify and select the checkbox that corresponds to the unit ID. After selecting the checkbox, click the modify unit button. This action will open the modify unit window.



LOAMS
Lube Oil Analysis Management System

BUREAU VERITAS

HOME ACTIONS SAMPLES LABELS **EQUIPMENT** ANALYTICS REPORTS DISTRIBUTION ADMIN CONFIG PREFERENCES

Equipment
Equipment / Browse Equipment

- ▼ BUREAU VERITAS
 - ▶ AGCO
 - ▼ BUREAU VERITAS
 - ▼ ABC Company Worksite 1
 - ▶ 834713 International 3800
 - ▶ 855326 International TRUCK
 - ▶ 864686 International DT466E
 - ▶ 906754 International 7000 SERIES
 - ▼ ABC Company Worksite 2
 - ▶ 8654323 International 1400 SERIES

ALL ABC COMPANY WORKSITE 1 UNITS

+ ADD MODIFY COPY DELETE

DOWNLOAD IMPORT UNITS

<input type="checkbox"/>	UNIT ID	EQUIPMENT TYPE	MANUFACTURER	MODEL	SERIAL
<input type="checkbox"/>	647836	TRUCKS (CLASS 5-8)	INTERNATIONAL	1400 SERIES	12345
<input type="checkbox"/>	834713	TRUCKS (CLASS 5-8)	INTERNATIONAL	3800	
<input type="checkbox"/>	855326	TRUCKS (CLASS 5-8)	INTERNATIONAL	TRUCK	
<input type="checkbox"/>	864686	REFUSE TRUCK	INTERNATIONAL	DT466E	
<input type="checkbox"/>	906754	REFUSE TRUCK	INTERNATIONAL	7000 SERIES	

Showing 100 rows

1 of 1 << >>



Modifying Mobile Equipment

4 In the modify unit window, you can make changes to the unit ID, serial number, unit of measurement for age units, unit year age and modify components. Components are listed within the graph type column and can be modified by making a click on the specific component you plan to modify.

5 After clicking a specific unit, you now have access to edit more details related to that specific component. Click done and then click the save and close button to save your changes. You have successfully modified your mobile equipment.

MODIFY UNIT ×

Industrial Mobile

1. Select Make/Model*

[Request New Make and Model](#)

2. Unit Info

Unit ID*	Serial Number	Age Units	Year
<input type="text" value="834713"/>	<input type="text"/>	Hr ▾	<input type="text"/>

3. Components

<input type="checkbox"/>	COMPONENT	MANUFACTURER	MODEL	SERIAL
<input checked="" type="checkbox"/>	COOLING SYSTEM	INTERNATIONAL	3800	
<input checked="" type="checkbox"/>	FRONT DIFFERENTIAL	INTERNATIONAL	3800	
<input checked="" type="checkbox"/>	REAR DIFFERENTIAL	INTERNATIONAL	3800	
<input checked="" type="checkbox"/>	ENGINE	INTERNATIONAL	3800	
<input checked="" type="checkbox"/>	HYDRAULIC	INTERNATIONAL	3800	
<input checked="" type="checkbox"/>	STEERING	INTERNATIONAL	3800	
<input checked="" type="checkbox"/>	TRANS-AUTO	INTERNATIONAL	3800	
<input checked="" type="checkbox"/>	TRANSMISSION - MANUAL	INTERNATIONAL	3800	

3. Components

Component	Component Manufacturer / Model*	Serial Number
<input type="text" value="COOLING SYSTEM"/>	<input type="text" value="International 3800"/> <input type="button" value="Q"/>	<input type="text"/>
Oil Type	Oil Capacity	Oil Units
<input type="text"/> <input type="button" value="Q"/>	<input type="text"/>	<input type="text"/>
Sample Frequency (days)		
<input type="text"/>		

[+ Request New Oil Type](#)



LOAMS — The Lube Oil Analysis Management System — by Bureau Veritas gives you access to real-time oil analysis data from your computer, tablet or mobile device. LOAMS is:

- +** **Cloud-Based** Multiple graphing functions allow users to create custom graphs to plot trends and compare equipment.
- +** **Scalable** LOAMS can be scaled to match your needs.
- +** **Configurable** Data access, user permissions and system functionalities can be configured by user or company.
- +** **Customizable** Users can customize the application to manage data according to individual needs and preferences.
- +** **Simple** User-friendly interface provides a simple and easy-to-use application for all skill levels.



LOAMS SUPPORT DESK

Phone: 1.800.655.4473

Email: LOAMS@us.bureauveritas.com

